



CASA-MS




Four modes on arm multi-functional adjustment:




a. Fully rotational arms that can be locked by turning knob.



b. Turn arm knob anti-clockwise to adjust arm height to desired position and tighten knob to lock.



c. Use alan key(attach) to adjust armrest width.



d. Free floating swing rotational movement of arms for ideal working positions.

Four modes adjustment on stool:

1. Seat with 5 degrees of forward tilt and 6 degrees rearward.
2. Back with 24 degrees of movement with 10 degrees forward and 14 degrees rearward.
3. Back with height adjustment.
4. Seat height adjustment.